



# F1020, Fuel Can fitting set

Drill two holes (Dia. 6mm) upon cap of fuel bottle. Between the two holes should be with 16mm distance.



Fit Fuel Exit Adapter upon cap.

Fit Filter Bracket upon cap.



Tube length same as fuel can height or more longer.


Fit Draw Filter to tube.

12

34

Could for both Electronic or Hand crank fuel pump.

When not using, could put Fuel Filter upon Bracket.



Fuel Filter

